

Bluetooth® Headset



Blade IV

BERVETT®

| Contents |

In the Package	4
Part Description	4

How to use

Charging	5
Power on / off	6
Pairing	6

Call usage

Making a call	7
Answering a call	8
Ending a call	8
Reject a call	8
Volume Control	8
Transferring a Call	9

Appendix

Precautions for safety	10
Specification & Characteristic	11
Limited Warranty	12

The BerNett Blade IV Bluetooth® Headset is a light weight wireless Headset utilizing Bluetooth® technology. This product can be used as an audio accessory for devices supporting either the Headset or Handsfree Bluetooth® Profiles. Bluetooth® is a trademark owned by Bluetooth® SIG, Inc. and is used by the manufacturer under its license term.

In the Package



Blade IV Headset




Charging Adapter



User's Manual

Part Description



How to use

Charging

Blade IV comes with a built-in rechargeable battery. Before using the headset, it is recommended that you fully charge the battery.

1. Plug the charger into the Charging Inlet of headset.

While charging, the LED indicator will show a solid blue light.



2. The charging time is less than 2 hours.

When the charging is completed, the LED indicator will turn off.



notice

Using other chargers which are not supplied by the manufacturer may cause the headset damaged. While charging, you can not use headset.

Power on/off

	Action	Sound	LED Indicator
Power on	Press and hold the MFB for more than 2 seconds.	Power on with 4 times beep sound.	LED indicator will flash every 3 seconds.
Power off	Press and hold the MFB for more than 5 seconds.	Power off with 3 times beep sound.	LED indicator will turn off. Blue light remains on until the MFB is released.

Pairing

1. As the headset turned off, then press and hold the MFB for more than 7 seconds.
2. You will hear a melody announcing pairable state.
3. While the pairable state, the LED indicator will flash every 0.3 second.
4. Follow the user's manual of your handset.
5. Select BLADE IV from the list of device on your handset.
6. When asked for the Pass/Pin code during procedure, enter '0000' (4 Zeros).

7. If the pairing is completed successfully, you will hear a beep. And LED indicator will flash every 3 seconds.

Call usage

Making a call

1. Making a call

When you make a call from your handset, the call will be automatically transferred to the headset. If not automatically transferred, you can transfer the call manually by briefly pressing the MFB.

2. Last number redialing

Press and hold MFB for 2 seconds.

3. Voice dialing

Briefly press MFB then state the voice tag.



Tip

This is available only when your handset supports the voice dialing function.

Answering a call

When there is an incoming call, you will hear ringing through the earphone. Simply press the MFB to accept the call.

Ending a call

Briefly press the MFB or press end button on your handset.

Reject a call

During ringing, press and hold the MFB for more than 2 seconds.



Tip

This is available only when your headset is connected with your handset through HANSDFREE profile.

Volume Control

Press VOLUME BUTTON [+] or [-] on the headset to increase or decrease the speaker volume.

Transferring a Call

From Handset to Headset : Briefly press the MFB.

From Headset to Handset : Press VOLUME [+] or [-] BUTTON for more than 2 seconds.



Pay attention not to press the MFB for too long time, then headset will turn off.

Appendix

Precautions for safety

- ! Keep a place of safety with turning off headset.
- ! Do not place the headset under over 50 °C high temperature or a direct ray of light. It may cause to lower of performance and reduce battery life.
- ! Keep the accessory with headset away from humidity & dust.
- ! Do not drop the headset from high place.
- ! Do not touch headset and plug with a wet hand.
- ! Do not expose directly to the water, alcohol, benzene etc.
- ! Pay attention that a baby or pet do not be sucking or biting headset.
- ! Do not modify, repair, take a part at discretion.
- ! Turn off at the place of banning Headset using.
- ! If possible, do not use while driving.
- ! Keep the headset away from micro-wave or wireless LAN. It may cause a noise.

Specification & Characteristic

Bluetooth® version	Bluetooth® Ver2.0 Compatible
Supported Bluetooth® profile	Headset/Handsfree Profile
Carrier frequency	2.402 ~ 2.480 GHz
Operating range	Up to 10m
Dimension (mm)	50(L) x 18(W) x 12(H)
Weight	10.3g
Operating temperature	-10 °C ~ +60 °C
Talking Time	Up to 5 hours
Stand-by time	Up to 120 hours
Charging time	less than 2 hours

Made in Korea by SEECODE

BERNETT[®]

<http://www.metallicanditsystem.com>

Call 66 82 5306440

 **Bluetooth**    **RoHS**

Bluetooth® Headset



Blade IV

BERVETT®

| สารบัญ |

อุปกรณ์ภายในกล่อง	4
ส่วนประกอบต่างๆของหูฟัง	4

วิธีการใช้

การชาร์จหูฟัง	5
การเปิดปิดเครื่อง	6
การเชื่อมต่อ	6

การใช้งานกับโทรศัพท์

โทรออก	7
รับสาย	8
วางสาย	8
ปฏิเสธสายเรียกเข้า	8
การปรับเสียง	8
โอนสาย	9

ภาคผนวก

ข้อควรระวังเพื่อความปลอดภัย	10
คุณสมบัติและข้อมูลเชิงเทคนิค	11
เงื่อนไขการรับประกัน	12

หูฟังบลูทูธ เบอร์เน็ต รุ่น เบลดโฟร์ เป็นหูฟังไร้สายซึ่งสามารถใช้ร่วมกับอุปกรณ์ที่รองรับ Bluetooth Headset Profile หรือ Bluetooth Handsfree Profile. Bluetooth เป็นเครื่องหมายการค้าของ Bluetooth SIG, Inc และถูกใช้ภายใต้ลิขสิทธิ์ โดยผู้ผลิต

อุปกรณ์ภายในกล่อง



Blade IV Headset




Charging Adapter



User's Manual

ส่วนประกอบต่างๆของตัวเครื่อง



วิธีการใช้

| การชาร์จหูฟัง |

หูฟังรุ่นเบสโพรใช้แบตเตอรี่แบบประจุไฟใหม่ได้.เราขอแนะนำให้คุณชาร์จหูฟังให้เต็มก่อนการใช้งานครั้งแรก

1. เสียบที่ชาร์จเข้ากับหูฟัง

ขณะประจุไฟ สัญญาณไฟที่หูฟังจะค้างเป็นสีน้ำเงิน



2. ระยะเวลาการชาร์จประมาณ 2 ชั่วโมง

เมื่อหูฟังประจุไฟเต็มแล้ว สัญญาณไฟที่หูฟังจะดับลง



หมายเหตุ

การใช้ที่ชาร์จที่ไม่ได้รับการรับรองจากผู้ผลิตอาจทำความเสียหายให้กับหูฟังได้

การเปิดปิดเครื่อง

	วิธี	เสียง	สัญญาณไฟ
เปิด	กดปุ่ม MFB ค้างไว้ 3 วินาที	มีสัญญาณเสียงออกจากหูฟัง 4 ครั้ง	สัญญาณไฟกระพริบทุก 3 วินาที
ปิด	มีสัญญาณเสียงออกจากหูฟัง 5 ครั้ง	มีสัญญาณเสียงออกจากหูฟัง 3 ครั้ง	สัญญาณไฟค้างเป็นสีน้ำเงินและดับลงเมื่อปล่อยปุ่ม MFB

การเชื่อมต่อ

1. ขณะหูฟังปิด, กดปุ่ม MFB ค้างไว้ 7 วินาที
2. จะมีเสียงเตือนออกจากในหูฟัง
3. สัญญาณไฟจะกระพริบทุกๆ 0.3 วินาที
4. สั่งให้โทรศัพท์ทำการค้นหาอุปกรณ์บลูทูธ (โปรดอ้างอิงจากคู่มือโทรศัพท์ของคุณ)
5. เลือก BerNett Blade IV จากรายชื่ออุปกรณ์
6. เมื่อหน้าจอโทรศัพท์ขึ้นให้ทำการป้อน รหัสผ่าน ให้ใส่ '0000' (ศูนย์สี่ตัว)

7. เมื่อการเชื่อมต่อสมบูรณ์ จะมีเสียงบีบออกจากหูฟัง และ สัญญาณไฟจะกระพริบทุก 3 วินาที

การใช้งานกับโทรศัพท์

| โทรออก |

1. โทรออก

กดโทรออกจากโทรศัพท์ตามปกติ เสียงจะถูกโอนไปที่หูฟังโดยอัตโนมัติ

2. โทรออกเบอร์ที่โทรล่าสุด

กดปุ่ม MFB ค้างไว้ 3 วินาที

3. โทรออกด้วยเสียง

กดปุ่ม MFB แล้วปล่อยจากนั้นพูดชื่อที่ต้องการโทรออก



หมายเหตุ

การโทรออกด้วยเสียงใช้ได้กับโทรศัพท์ที่รองรับการโทรออกด้วยเสียง และ รองรับ Bluetooth Handsfree Profile เท่านั้น

รับสาย

เมื่อมีสายเข้า คุณจะได้ยินเสียงเตือนในหูฟัง กดปุ่ม MFB 1 ครั้ง เพื่อรับสาย

วางสาย

กดปุ่ม MFB 1 ครั้งเพื่อวางสาย

ปฏิเสธสายเรียกเข้า

ขณะมีเสียงเตือนสายเรียกเข้า กดปุ่ม MFB ค้างไว้ 3 วินาที



หมายเหตุ

ฟังก์ชันการปฏิเสธสายเรียกเข้าใช้ได้กับโทรศัพท์ที่รองรับ Bluetooth Handsfree Profile เท่านั้น

การปรับเสียง

กดปุ่มปรับเสียง [+] เพื่อเพิ่มระดับเสียง หรือ [-] เพื่อลดระดับเสียง

| โอนสาย |

จากโทรศัพท์ไปยังหูฟัง: กดปุ่ม MFB แล้วปล่อย

จากหูฟังไปยังโทรศัพท์: กดปุ่มปรับเสียง [+] หรือ [-] ค้างไว้ 2 วินาที
แล้วปล่อย



ระวังอย่ากด MFB นานเกินจนทำให้เป็นการ ปิด หูฟัง

ภาคผนวก

| ข้อควรระวังเพื่อความปลอดภัย |

- ! เก็บหูฟังไว้ในที่ปลอดภัยเมื่อไม่ได้ใช้งาน
- ! อย่าเก็บหูฟังไว้ในที่อุณหภูมิสูงกว่า 50 องศา และอย่านำหูฟังวางตากแดดเป็นระยะเวลานาน
- ! เก็บหูฟังไว้ในที่แห้งและปลอดภัยจากฝุ่นละออง
- ! ห้ามโยนหูฟังลงจากที่สูง
- ! ห้ามสัมผัสหูฟังขณะมือเปียก
- ! ห้ามนำหูฟังไปสัมผัสกับของเหลว
- ! เก็บหูฟังให้พ้นจากเด็กทารก และ สัตว์เลี้ยง
- ! ห้ามดัดแปลงหูฟัง
- ! ปิดหูฟังในที่ห้ามใช้ เช่น บนเครื่องบิน
- ! เก็บหูฟังให้พ้นจากคลื่นไมโครเวฟ

คุณสมบัติและข้อมูลเชิงเทคนิค

Bluetooth® version	Bluetooth® Ver2.0 Compatible
Supported Bluetooth® profile	Headset/Handsfree Profile
Carrier frequency	2.402 ~ 2.480 GHz
Operating range	Up to 10m
Dimension (mm)	50(L) x 18(W) x 12(H)
Weight	10.3g
Operating temperature	-10 °C ~ +60 °C
Talking Time	Up to 5 hours
Stand-by time	Up to 120 hours
Charging time	less than 2 hours

Made in Korea by SEECODE

BERNETT[®]

<http://www.metallicanditsystem.com>

Call 66 82 5306440

 **Bluetooth**    **RoHS**